



Plate Fitting Instructions

Please follow the instructions for fitting the bath and plate.

IT IS IMPORTANT TO ENSURE THAT THE PLATE IS FITTED ON A LEVEL SURFACE AND THAT THE BATH IS INSTALLED BY A QUALIFIED PLUMBER.

Secure the plate to the floor by drilling seven evenly placed holes 30mm from the edge. Please countersink the holes to stop the screws from protruding and having contact with the base of the bath. Any contact may alter the levels and adhesion.

In some cases the plates may be pre-drilled.

Important notice; the plate is flexible please do not worry if it is not flat. The plate will flex once it is screwed and secured to the floor. After the plate has been fixed to the floor ensure that the waste kit is fitted to the bath along with all necessary pipe work. Please test for leaks before fixing bath to plate. Once secured this bath cannot be removed.

The baths come with the fixing compound please follow the instructions for cleaning the base of bath and plate.

BEFORE MIXING THE COMPOUND:

- 1) Wipe the base of the bath and the top of the mounting plate with an isopropyl alcohol (IPA) wipe to degrease the surfaces. These are supplied.
- 2) Fit nozzle to adhesive cartridge and mount cartridge into gun.
- 3) Apply adhesive to mounting plate.
- 4) Fit bath onto mounting plate within 10 mins. Check no adhesive is visible on outside of bath.
- 5) Adhesive will start to cure in 20mins, but do not move bath for at least TWO hours to ensure bond isn't broken.