

Polishing Repair Kit

These simple instructions relate to the use of the Ashton & Bentley Polishing Repair Kit. Please follow the simple step by step guide below to remove the scratch or blemish from the surface of your bath or basin – and return the finish to its original condition.



A&B Polishing Kit Contents

- 3M arbour, yellow Velcro sponge, mop head
- White fine Durabuild polish
- Applicator stick
- Bucket & lid

Matt Finishes

1. Judge the severity of the scratch and start with the finest grit wet & dry sandpaper as possible to remove the scratch (possibly 1000 or 1200 grit paper).
2. To minimize the dust, keep the sandpaper wet.
3. Rub over the scratch in straight lines to remove it, periodically switching your rubbing direction by 90°.
4. Take care not to sand a groove in the surface.
5. Rub until all of the scratch is removed.
6. Clean the area with water and select the next lighter grit sandpaper
7. Repeat process rubbing over an extended area to blend the sanding in.
8. Continue this process until you have sanded with 1500 grade wet & dry sandpaper.
9. At this point the area should show a soft sheen.
10. Clean the area and allow to dry.

Gloss Finishes

1. Judge the severity of the scratch and start with the finest grit wet & dry sandpaper as possible to remove the scratch (possibly 1000 or 1200 grit paper).
2. To minimize the dust, keep the sandpaper wet.
3. Rub over the scratch in straight lines to remove it, periodically switching your rubbing direction by 90°.
4. Take care not to sand a groove in the surface.
5. Rub until all of the scratch is removed.
6. Clean the area with water and select the next lighter grit sandpaper
7. Repeat process rubbing over an extended area to blend the sanding in.
8. Continue this process until you have sanded with 1500 grade wet & dry sandpaper.
9. At this point the area should show a soft sheen.
10. Using a soft cloth, you can now polish the area up to a gloss finish with automotive paint polishing compound such as T-Cut® or the A&B polishing compound.
11. If you have the A&B supplied 3M lambswool polishing bonnet and arbor, screw them together and use an electric drill on slow speed to polish the area.
12. Keep the area covered in polishing compound
13. Don't let the area dry out whilst polishing and keep the drill speed slow.
14. Extend the polishing in a larger area to blend the surface finish.
15. Finish with a traditional car wax.