

Petra Bath Handling Process

The Petra bath weighs 195kg. It is unique in its size and weight. Furthermore, it's smooth design makes handling more difficult.

These instructions are written to ensure that each bath is handled in the correct way, to promote safe working practices and to protect the product.

They should be read fully prior to handling the bath. Ashton & Bentley will bear no liability for any injury to person or property as a result of not following these instructions.

Instructions

1. A minimum of 4 people should be used to lift and maneuverer the bath. Each person should be adequately trained in safe lifting.
2. Each bath is supplied with a carry bag. The bath should only be lifted using one of these.
3. To access the underside of the bath (i.e. to fit the waste);
 - a. Ensure that the area to the side of the bath is flat, smooth and free from any obstructions.
 - b. Lay a thin, protective layer to the side of the bath (such as foam), ensuring this is also flat.
 - c. Gently roll the bath onto its long side.
 - d. Securely hold the bath in place whilst another individual carries out the work.
 - e. Gently roll the bath back upright.
4. Take care not to drop the bath, even from a small height. The weight of the bath is such, that any impact may damage the bath or the floor.